

### Diagram 17

|           |        |           |        |    |                        |     |                                         |     |                                |
|-----------|--------|-----------|--------|----|------------------------|-----|-----------------------------------------|-----|--------------------------------|
| <b>BA</b> | White  | <b>OR</b> | Orange | 1  | Battery                | 56  | Vehicle speed sensor                    | 214 | Canister purge solenoid        |
| <b>BE</b> | Blue   | <b>RG</b> | Red    | 2  | Ignition switch        | 70  | Fuel gauge sender unit/fuel pump        | 215 | Knock sensor                   |
| <b>BG</b> | Beige  | <b>RS</b> | Pink   | 4  | Maxifuse unit 1        | 205 | Engine management double function relay | 216 | Engine coolant temp. sensor    |
| <b>GR</b> | Grey   | <b>VE</b> | Green  | 5  | Passenger fusebox      | 206 | Ignition coil                           | 217 | Throttle position sensor       |
| <b>JN</b> | Yellow | <b>VI</b> | Mauve  | 8  | Diagnostic connector   | 207 | Engine management control unit          | 218 | MAP sensor                     |
| <b>MR</b> | Brown  | <b>VJ</b> | Green/ | 15 | Engine fusebox         | 208 | Idle speed stepper motor                | 219 | Inlet air temp. sensor         |
| <b>NR</b> | Black  |           | Yellow | 54 | Instrument cluster     | 209 | Engine speed sensor                     | 220 | Power steering pressure switch |
|           |        |           |        |    | b = speedometer        | 210 | Oxygen sensor                           | 221 | Fuel injector                  |
|           |        |           |        |    | c = tachometer         | 211 | Spark plug                              |     |                                |
|           |        |           |        |    | c1 = engine management | 212 | Inertia switch                          |     |                                |
|           |        |           |        |    | warning light          | 213 | Throttle housing heater                 |     |                                |

H33006

### Typical MM1AP fuel injection system

