

INFORMATION : FAULT CODE P0104 (ENGINE ECU)

MOUNTING BOSCH AND DIESEL TURBO DV6TED4 WITHOUT FAP OR MOUNTING BOSCH AND DV6ATED4 TURBO DIESEL OR MOUNTING BOSCH AND DIESEL TURBO DV6TED4 90HP FAP OR MOUNTING BOSCH AND DIESEL TURBO DV6TED4 FAP

MOUNTING BOSCH AND DIESEL TURBO DV6TED4 WITHOUT FAP OR MOUNTING BOSCH AND DIESEL TURBO DV6TED4 90HP FAP OR MOUNTING BOSCH AND DV6ATED4 TURBO DIESEL OR MOUNTING BOSCH AND DIESEL TURBO DV6TED4 FAP

Engine ECU BOSCH EDC16C34	
Fault code	P0104
After sales description of the fault code	Flowmeter signal : Open circuit or short circuit to positive or short circuit to earth
Description of the diagnostics	The ECU detects a short-circuit on the harness of the air flowmeter : Open circuit or short circuit to positive or short circuit to earth (For 1,2 seconds)
Conditions of activation of the diagnostics	Consult the associated contexts for the Pcode forwarding conditions
Conditions of disappearance of the fault	Ignition on
Down-grade modes if fault present	The ECU uses a replacement value for the air flow
	Deactivation of the coherence faults of the flowmeter
	The ECU cuts the regulation of the EGR valve
	The ECU cuts the regulation of the EGR valve
	The ECU cuts the regulation of the bypass mixer
Switching on of the warning light and/or warning message	Warning lamp MIL
Main customer complaints likely	Lack of power
Suspect areas	Air flow meter
	Electrical harness
	Connectors